

## TUBULAR HEATER INSTRUCTION MANUAL



### Tubular Heater Type Two: TH01B/ TH02B /TH03B/TH04B

**YOU SHOULD READ THE MANUAL CAREFULLY BEFORE USING,  
AND KKEEP THE MANUAL WELL.**


#### DISPOSAL



This symbol indicates that this product must not be placed in general household waste. It should be sent to a separate recycling facility for recovery, check Local Authorities for details.

By responsible recycling and separating this product from other household waste it will help protect the environment and human health, as the volume of waste sent to incinerators or land-fills will be reduced and natural resources conserved.

Read all the instructions prior to use.



**WARNING:** Check product before use. If cord is damaged, it must be replaced by the manufacturer if still under warranty, or a similar qualified person to avoid any hazards

### 1. Safety Regulations

- The tubular heater is not suitable for use outdoors in damp weather.
- **Do not** submerge into water.
- Place in a safe place away from flammable objects.
- **Do not** place flammable liquids or gasses near the heater.
- **Do not** place the heater directly below the socket outlet.
- **Do not** let the power cord over hang or touch the tube.
- **Keep out of reach of children and animals** – product gets hot to touch.
- **This is not a toy.**
- Switch off appliance when not in use.
- **Do not** hold the tubular heater by the cord.
- If using an extension cord it must be as short as possible and fully extended.
- Check heater regularly if using with a timer or any other device that switches the tubular heater on or off automatically.
- This leaflet should be retained for instructions on use.

### 2. Cleaning

Ensure product is unplugged from the mains. Ensure product is completely cold. Wipe with a damp cloth, then finish by drying with a soft cloth. **DO NOT** use abrasive cleaning powders, clothes or metal polishes on any part of the tubular heater as this will cause damage.


### 3. Thermal Cut-out

The appliance is fitted with a thermal cut-out. Once the tubular heater has cooled down it will re-set itself automatically. It will then switch on and off until the reason for overheating has been removed.


### 4. Operation

**Please keep horizontal installation, vertical installation is prohibited.**

**Notice:** DO NOT SWITCH POWER ON TO THE HEATER UNTIL IT IS SECURELY MOUNTED .



**Step 1.** Install the bracket as the picture showed .



**Step 2.** Fix the tubular heater on the wall or on the floor like the following picture showed .



### 6. Tubular Heater Notice :

- When the room has reached the desired temperature, turn the thermostat knob in an anti-clockwise direction just until a small sound heard and not beyond.
- The temperature will then be regulated and kept at a constant level by the thermostat.
- The heater is fitted with a safety device which will switch off the heater in case of accidental overheating .
- To reset, turn down the heater switch for a few minutes to allow the unit to cool down.
- Make sure that any causes of overheating, such as obstructions, are removed and plug the appliance in again.
- Turn down the switch when it is summer or nobody at home or no need to keep heating , please turn down the switch , then you will see the light is off , it is energy saving and more safe .

### 7. Tubular heater Specifications

Model No.	Power	Electrical Supply	IP Rating	Product Length (mm)	Product Size (mm)
TH01B	60W	220-240V ,50 Hz	IP44	300mm	385*95*90
TH02B	120W	220-240V ,50 Hz	IP44	609mm	685*95*90
TH03B	180W	220-240V ,50 Hz	IP44	900mm	995*95*90
TH04B	240W	220-240V ,50 Hz	IP44	1200mm	1295*95*90

### 8. Warranty

This product is guaranteed under warranty and covers defects in material or workmanship from 1 year of date of purchase. The original bill of purchase (with purchase date) must be submitted. The warranty will not apply in cases of: Misuse: by non-compliance of the instructions, normal wear and tear, incorrect use, e.g. overloading, non-approved accessories, force or damaged

caused by external forces, if the plug has been tampered with or removed, partially or completely dismantled product, or interference by non-qualified persons

Elixir Garden supplies  
unit 1, Middlegate, Whitelund, Morecambe, LA3 3BN